



10 Riverside Dr.,
Trenton, ON K8V 5P8 Canada
Ph: (613)392-1402 Fax:(613) 392-1401
Email: info@mkrcabinets.com Toll free: 1-800-757-1235

MKR Dental Cabinets' Care & Maintenance Guidelines

With proper care and maintenance, such as regular dusting and cleaning spatters and spills, you can help maintain the beauty and integrity of your cabinets by following these recommendations.

Exterior and Interior Cabinet Surfaces

Use a soft cotton cloth dampened with warm water to clean your cabinets. For more thorough cleaning, please use a fresh solution of mild hand dishwashing liquid mixed with warm water. After cleaning, wipe all surfaces with a clean, damp cloth. Dry immediately using another soft, clean cloth.

Glass Shelves and Door Inserts

Windex and a clean, soft microfibre cloth may be used to clean glass surfaces. A solution of water and vinegar may also be used.

Countertops

Acrylic Solid Surface

Wipe up any spills as soon as possible with a damp microfiber cloth. Standard household kitchen spray should remove most stains. Minimize direct heat exposure to protect the surface and your investment. Never chop on your acrylic solid surface top.

Laminate

To care for your laminate countertops, wipe counters with a damp, soft cloth using warm water and a mild hand dishwashing detergent. Never apply heat to your laminate countertops. Be cautious of performing repetitive movements on laminate (ie. Pulling a coffee maker in and out each day), as these movements can wear the finish.